

Digi TV Liste de Fréquences

Fréquence	Pol	SR	Fec	Standard	Modulation	Paquet
11747	H	28000	5/6	DVB-S	QPSK	MX1
11823	H	30000	5/6	DVB-S2	8PSK	Digi TV
11900	H	28000	5/6	DVB-S	QPSK	Digi TV
11938	H	28000	7/8	DVB-S	QPSK	UPC Direct
11958	V	28000	7/8	DVB-S	QPSK	UPC Direct
11977	H	30000	3/4	DVB-S2	8PSK	Digi TV
12054	H	30000	3/4	DVB-S2	8PSK	Digi TV
12380	V	30000	3/4	DVB-S2	8PSK	Digi TV
12527	H	27500	3/4	DVB-S	QPSK	Digi TV
12563	V	27500	3/4	DVB-S	QPSK	Digi TV
12563	H	27500	3/4	DVB-S	QPSK	Digi TV
12607	H	27500	3/4	DVB-S	QPSK	Digi TV
12607	V	26666	2/3	DVB-S2	8PSK	Digi TV
12643	H	27500	3/4	DVB-S	QPSK	Digi TV
12643	V	26666	2/3	DVB-S2	8PSK	Digi TV
12687	H	27500	3/4	DVB-S	QPSK	Digi TV
12723	H	27500	3/4	DVB-S	QPSK	Digi TV