

Tricolor TV Liste de Fr quences

Fr�quenc	Pol	SR	Fec	Standard	Modulation	Paquet
11727	L	27500	3/4	DVB-S2	8PSK	Tricolor TV
11747	R	27500	3/4	DVB-S2	8PSK	Tricolor TV
11766	L	27500	3/4	DVB-S2	8PSK	Tricolor TV
11804	L	27500	3/4	DVB-S2	8PSK	Tricolor TV
11843	L	27500	3/4	DVB-S2	8PSK	Tricolor TV
11881	L	27500	3/4	DVB-S2	8PSK	Tricolor TV Sibir
11881	L	27500	3/4	DVB-S2	8PSK	Tricolor TV
11919	L	27500	3/4	DVB-S2	8PSK	Tricolor TV
11919	L	27500	3/4	DVB-S2	8PSK	Tricolor TV Sibir
11958	L	27500	3/4	DVB-S2	8PSK	Tricolor TV
11958	L	27500	3/4	DVB-S2	8PSK	Tricolor TV Sibir
11996	L	27500	3/4	DVB-S2	8PSK	Tricolor TV Sibir
11996	L	27500	3/4	DVB-S2	8PSK	Tricolor TV
12034	L	27500	3/4	DVB-S2	8PSK	Tricolor TV Sibir
12034	L	27500	3/4	DVB-S2	8PSK	Tricolor TV
12054	R	27500	3/4	DVB-S2	8PSK	Tricolor TV
12073	L	27500	3/4	DVB-S2	8PSK	Tricolor TV Sibir
12073	L	27500	3/4	DVB-S2	8PSK	Tricolor TV
12111	L	27500	3/4	DVB-S2	8PSK	Tricolor TV
12111	L	27500	3/4	DVB-S2	8PSK	Tricolor TV Sibir
12149	L	27500	3/4	DVB-S	QPSK	Tricolor TV Sibir
12149	L	27500	3/4	DVB-S2	8PSK	Tricolor TV
12169	R	27500	3/4	DVB-S2	8PSK	Tricolor TV
12188	L	27500	3/4	DVB-S	QPSK	Tricolor TV Sibir
12190	L	22500	3/4	DVB-S2	8PSK	Tricolor TV
12226	L	27500	3/4	DVB-S	QPSK	Tricolor TV
12226	L	27500	3/4	DVB-S	QPSK	Tricolor TV Sibir
12265	L	27500	3/4	DVB-S2	8PSK	Tricolor TV Sibir
12303	L	27500	3/4	DVB-S2	8PSK	Tricolor TV Sibir
12303	L	27500	3/4	DVB-S2	8PSK	Tricolor TV
12341	L	27500	3/4	DVB-S2	8PSK	Tricolor TV Sibir
12360	R	27500	5/6	DVB-S2	8PSK	Tricolor TV
12380	L	27500	3/4	DVB-S2	8PSK	Tricolor TV
12418	L	27500	3/4	DVB-S2	8PSK	Tricolor TV
12456	L	27500	3/4	DVB-S2	8PSK	Tricolor TV
12476	R	27500	3/4	DVB-S2	8PSK	Tricolor TV