

## Digi TV Frekans Listesi

| Frekans | Pol | SR    | Fec | Standart | Modulasyon | Paket      |
|---------|-----|-------|-----|----------|------------|------------|
| 11747   | H   | 28000 | 5/6 | DVB-S    | QPSK       | MX1        |
| 11823   | H   | 30000 | 5/6 | DVB-S2   | 8PSK       | Digi TV    |
| 11900   | H   | 28000 | 5/6 | DVB-S    | QPSK       | Digi TV    |
| 11938   | H   | 28000 | 7/8 | DVB-S    | QPSK       | UPC Direct |
| 11958   | V   | 28000 | 7/8 | DVB-S    | QPSK       | UPC Direct |
| 11977   | H   | 30000 | 3/4 | DVB-S2   | 8PSK       | Digi TV    |
| 12054   | H   | 30000 | 3/4 | DVB-S2   | 8PSK       | Digi TV    |
| 12380   | V   | 30000 | 3/4 | DVB-S2   | 8PSK       | Digi TV    |
| 12527   | H   | 27500 | 3/4 | DVB-S    | QPSK       | Digi TV    |
| 12563   | V   | 27500 | 3/4 | DVB-S    | QPSK       | Digi TV    |
| 12563   | H   | 27500 | 3/4 | DVB-S    | QPSK       | Digi TV    |
| 12607   | H   | 27500 | 3/4 | DVB-S    | QPSK       | Digi TV    |
| 12607   | V   | 26666 | 2/3 | DVB-S2   | 8PSK       | Digi TV    |
| 12643   | H   | 27500 | 3/4 | DVB-S    | QPSK       | Digi TV    |
| 12643   | V   | 26666 | 2/3 | DVB-S2   | 8PSK       | Digi TV    |
| 12687   | H   | 27500 | 3/4 | DVB-S    | QPSK       | Digi TV    |
| 12723   | H   | 27500 | 3/4 | DVB-S    | QPSK       | Digi TV    |